How to Share Printer

- -Control Panel
- -Hardware and Sound
- Devices and Printers
- Right click the printer that you want and select printer properties.
- Sharing tab and Change sharing options
- Check share this printer. Make sure Render print jobs on client computers.
- -Apply and ok
- -Go back and select Network and Internet.
- -Network and Sharing Center
- -Change advanced and sharing options.
- -Turn on network discovery, Turn on file and printer sharing.
- -All networks arrow and Turn off password protected sharing.

We can't install this printer right now in windows

- -Control Panel
- -Hardware and Sound
- -Devices and Printers
- -Select the printer and then select remove device. And press yes
- -Close the tabs and search print management.
- -Select all drivers and on the right side select the printer having problem and delete it.
- -Close the tabs and restart.

How to fix printer error 1260 in Windows 10

- -Search run and msdt.exe /id PrinterDiagnostic
- -Click advanced and check the apply repairs automatically and next.
- -Apply this fix.
- -Restart your computer.

Can't print documents. Printer driver is unavailable in windows 10 FIX

- -Search Device Manager
- -Select Print queues and right click Microsoft Print to PDF.
- -Select update driver.
- -Browse my computer for driver software, select let me pick from a list of available driver from my computers.
- -Select Generic software devices and next. Close the tab.

Another Computer is Using the Printer Error Message in Windows 10/8/7

- -Turn off the printer and turn on again.
- -Search Services and look for print spooler service and select it and on the left side Restart the service.
- -Also double click it and make startup type Automatic.
- -Close the tabs and search for device manager, print queues and right click the my printer and update drivers.
- Open the file explorer and go to this pc, local disk c, windows, system32, spool folder, printers folder, select continue and if you see any thing there select all the things and delete it and restart your computer.

How to fix printer not activated error code-30

- -Turn off printer and turn on again.
- -Go to control panel, select Hardware and Sound / Devices and Printers / select the printer and right click on that and select set as default printer.
- Close the tab and search the device manager and expand print queues and select the printer and update drivers.

How to fix the "Printer Cannot be contacted over the network" error

- -Search for services and scroll down to remote access auto connection manager properties.
- -Double click it and make startup type to automatic. Click the Start and set apply and then ok.
- -Select the log on tab and set the This account: with password on that. Select ok and close the tabs.
- -Another way is to search control panel and select the devices and printers. Select the printer and right click on it and printer properties.
- -Select the ports and look for it wheather it is correct or not.

How to find your Printer IP address

-Command prompt and right click on the top bar, right click on the edit and paste (netstat -r) and hit enter on the keyboard.

How to List all installed printers in Windows 10

-Search Printers and scanners.

Current Printer is unavailable select another printer in excel error FIX

- -Search registry editor and run as administrator
- -Before make changes in the registory editor, make copy of all the files. For that
- -Click file and click on the export. Make the file name simple and keep the file stored as the backup.
 - -If needed to backup just click the import and select the backup file.
- -Click HKEY_CURRENT_USER/SOFTWARE/Microsoft/Windows NT/CurrentVersion/Windows, click the right and select permissions.
- -Select the user account, check the permission as full control and read allow.
- -You can add the users or groups.

Printer Offline Windows, Cannot configure Port Solution in Windows 10

- -Search for Devices and Printers
- -Right click on the printer and click printer properties.
- -Select ports and Standard TCP/IP Port should be checked marked.
- -Select configure port and uncheck the SNMP status enabled and apply. Restart pc and printer.

How to install and Update Your Printer Drivers

- -Search Control Panel and select Hardware and Sound.
- -Select add a device under the Hardware and Sound.
- -If not made like this, click on the hardware and sound.
- -Click the advanced printer setup and though if not listed click the The printer that I want isn't listed.
- -Select the Add a local printer or network printer with manual settings and next.
- -Select next and choose the manufacturer and model then select next.
- -Next and finish the process. Now restart your pc and printer.

For updating the drivers.

-Search about the printer name and model on the browser and go to the official page of printer company and download the drivers.

How to Remove Stubborn Printer Drivers on Windows (imp)

- -Search mmc and tap file, then add/remove snap-in.
- -Scroll to the print management and add.
- -Click the add the local server and click finish and ok.
- -Now expand the print management and Print servers.
- -Expand the local server and printers and on the right side you will see the drivers. Now to delete right click on the driver and delete it. If not deleted then search for services and search for Print Spooler and stop that. Now try to delete it and again unable for delete then start and try again.

-If this also doesnot works then search for Device Manager and expand Print Queues and uninstall the driver.

How to add a network printer (Imp)

- -Search for the devices and printers.
- -Click on the add a printer and click the "The printer that I want isn't listed".
- -Check the Add a printer using a TCP/IP address or hostname and next.
- -For Device type select the TCP/IP device and fill the hostname and portname and click next.

How to share a printer between multiple computers(network)

- -Search for printers and devices.
- -Right click and select the printer properties of the printer that you want to share.
- -Select the sharing and check mark the share this printer and rendering also.

How to fix printer offline issues

- -Search for printers and devices.
- -Right click on the printer that you want and select the printer properties.
- -Select the port and default will be automatically selected.
- -Click on the configure port and disable the SNMP.
- -Restart the computer and printer.

How to clear the printer Queue/Spooler

- -Search devices and printer and right click in the printer and select whats printing.
- -Search services, search for print spooler and right click on it and stop it.
- -Search for show hidden files and folders, select hidden files to show.
- -Search for file explorer and go to c drive/windows/system32/spool/printers, delete all the files there.
- -Go back and start the print spooler.